

EasyStart Sandbox Parts List

STEP 1

D  2x


E  4x


A  4x


B  4x


C  2x

STEP 2

I  16x

H  8x

F  2x

G  2x

STEP 3

L  4x


M  4x


N  4x


J  1x


K  1x


STEP 4


T  4x


M  4x


N  4x


R  2x

S  1x

O  1x

P  1x

Q  1x

I  4x

STEP 5

U  2x

STEP 6

I  5x

X  1x



V  1x

W  1x


Y  1x

EasyStart Sandbox Assembly



1



2




3



4

5



6



SAFETY PIN/HANDLE MUST BE PUSHED THROUGH WHEN IN USE!

**Customer Service: 877-760-8500
Exaco Trading, Austin Texas**